

This data will update the firmware of your HD-300 from V1.10 or V2.00 to V2.01. Please read the instruction manual included in the Updater carefully and update the firmware correctly.

#### 1. Update details

- Fixed a problem that prevented the settings from being saved to the instrument in rare cases.
- Fixed minor problems.

After updating to V2.01, the startup screen will appear for approximately 20 seconds only when the power is turned on for the first time, so please wait as it is.

#### 2. Cautions

After updating to V2.01, all settings will be returned to initial default. Please make sure to record the user tuning and beat/tempo memory in advance in a memo, or save them in the HD-300 Assistant iOS app.

HD-300	V1.10	V2.00	V2.01
--------	-------	-------	-------

